

















the flying paint balls

Move your arms around to pop



Use the coloured blocks to build a tower that matches the pattern Magician Bootle makes



Flap your arms like a bird to make Owl Bootle fly & lean your body to steer the direction of flight






Play different musical instruments to perform activities in the game




HARDWARE SET-UP

Inserting battery into remote:

- 1. Twist the battery cap counter-clockwise to open
- Locate your CR2032 coin cell battery (if present, remove clear plastic wrapping from battery)
- Insert one edge first, with the battery oriented diagonally, then press the battery down into the rest of the battery slot
- 4. The battery should be inserted "+" side up (facing you)
- 5. Twist the battery cap clockwise to close





Game Set-Up

- Connect the HDMI cable to the HDMI socket (C) on the Persee and on the TV
- Connect the power cable to the DCIN socket (A) on the Persee and an electrical outlet
 - If the power cable doesn't reach an outlet, use an extension cord
- 3. Place the Persee either on top of or in front of your TV
- 4. Angle the camera to provide an optimal view of your play space
 - Minimize bright lights in the background as it may interfere with the camera's ability to track movement
- 5. After placing the Persee in the proper position, move to an optimized tracking area 1 4 metres from the unit



Refer to the image on the left as reference for what your body should look like on the camera

- Turn on your TV and adjust the TV settings to the corresponding HDMI input.
- If the Persee doesn't power on automatically, press the power button on the Persee remote
- 8. A screen will automatically display informing you to set the correct date and time in the system. The best way to do this is to enter in your Wi-Fi network details. We encourage that you set your date, time and Wi-Fi connection correctly as it allows the system to log your playtime accurately & without interruption!
 - If you don't have a reliable Wi-Fi connection, you can establish an Ethernet connection by connecting to the LAN port (E) on the Persee

FIRST TIME SET-UP



Botley has asked you to help him track down all of the Bootles that have overrun Sky Spark City. Look inside each of the 5 headquarters to find different mini games you can play. By playing these games, you'll help Botley collect those pesky Bootles and discover some surprises along the way!



Raise your hand to get started



Use the remote to pick which movements you can do



Meet Botley and raise your hand to help him catch Bootles



Customize a Helper Bot



Raise your hand to pick how long you'd like to play each day



0

Help Botley to wash the window using your hands. Remember to use one hand at a time!



Sky Spark City is where you'll play all the mini games. Play Jetpack Bootle in the Inventor HQ!

PLAYING BOOTLE BLAST



Raise your hand to get started



Raise your hand to pick a highlighted minigame



Finished the game? Collect some Bootles!



Visit the Maker Max 3000 in the Inventor HQ to spend your coins



hand to pick a highlighted headquarter

Raise your



Play the mini game



Daily mission complete? Collect some coins!



Press any arrow key on the remote to navigate The Park!